

# User Guide

## ORI *Single-Fill Nitrogen Charge Kit*

Do not over-pressure system beyond gauge maximum limit or damage will result to gauge

Attach this hose with 1/4 NPT fitting to nitrogen regulator. Do not set regulator pressure beyond maximum pressure of charge kit gauge.

*Note: A quick disconnect coupling of sufficient pressure rating can be installed between 1/4 NPT fitting and regulator if desired (not included).*

To vent shock pressure:

- 1 Close lower valve
- 2 Remove valve cap
- 3 Depress valve core

- 1 Open T-handle all the way counter-clockwise before attaching connection valve to shock Schrader valve or shock pressure will vent prematurely.
- 2 Tighten hex nut securely to shock Schrader valve.
- 3 Turn T-handle all the way clockwise to depress shock Schrader valve core to add or vent pressure from shock.
- 4 Open T-handle all the way counter-clockwise before removing connection valve from shock.

Twist 1/4 turn clockwise to close valve.  
In-line is open

Close before venting pressure

